

**TDFM-136**

**CAP Digital FM Radio**

**Power Up**

1. Aircraft Master Power – On
2. Aircraft Avionics Power – On
3. Main/Off Switch – Set to Main

**Volume**

1. Guard Switch – Turn to adjust volume

**Normal Operation**

1. MN/GD Switch – Set to MN (Main)
2. G1/G2 Switch – Set to G1
3. Hi/Lo Switch – Set to Hi

**Arrow Keys**

1. Left Arrow (# 4) – Moves Frequencies Back
2. Right Arrow (# 6) – Move Frequencies Forward
3. Up Arrow (# 2) – Brightens Display
4. Down Arrow (# 5) – Dims Display

**Scan Mode**

1. # 5 Key – Enables Scan of all Freq's (If set by Wing Communications staff)

**Guard Mode Operation**

If message received over Guard Freq – MN/GD set to GD, respond then reset to MN